



Item	Part No.	Description	Qty
1	CD2013TT-V4-01	Front Panel	1
2	CD2013TT-V4-02	Side Handle	2
3	CD2013TT-V4-03	Heating Element	1
4	CD2013TT-V4-04	Heating Element Bracket	2
5	CD2013TT-V4-05	Lower Support	1
6	CD2013TT-V4-06	Foot	2
7	CD2013TT-V4-07	Top Frame	1
8	CD2013TT-V4-08	Rotary Switch	1
9	CD2013TT-V4-09	Adjustable Thermostat	1
10	CD2013TT-V4-10	Internal Wire	1

Item	Part No.	Description	Qty
12	CD2013TT-V4-12	Cord Grip	1
13	CD2013TT-V4-13	Rotary Knob	1
14	CD2013TT-V4-14	Thermostat Knob	1
15	CD2013TT-V4-15	Indicator Light	1
16	CD2013TT-V4-16	Fan Cover	1
17	CD2013TT-V4-17	Fan	1
18	CD2013TT-V4-18	Motor	1
19	CD2013TT-V4-19	Timer	1
20	CD2013TT-V4-20	Timer Bracket	1
21	CD2013TT-V4-21	Rear Panel	1

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.